

PurgeAlarm™

Visual Alarm Indicator

Frequently Asked Questions

1. What is the PurgeAlarm™ Visual Alarm Indicator?

PurgeAlarm™ Visual Alarm Indicator is a traffic light style column to convey the alarm status of your PurgEye® Weld Purge Monitor®.

2. How is the PurgeAlarm™ Visual Alarm Indicator connected?

The **PurgeAlarm™** Visual Alarm Indicator is connected to the Weld Purge Monitor® through the PurgeNet™ Smart Cable.

3. What combinations of PurgeAlarm™ Visual Alarm Indicator are available?

The **PurgeAlarm™** Visual Alarm Indicator can be fitted with a single red light (stop) or green (go) and red light combination, which have a 360-degree visibility.

4. How does the PurgeAlarm™ Visual Alarm Indicator signal the Weld Purge Monitor® status?

The red indicator will be illuminated when the **PurgeAlarm™** Visual Alarm Indicator is enabled and is reading a value greater than the alarm threshold set by the user.

The green 'ok to weld' indicator (optional) will illuminate when readings are lower than the alarm threshold set by the user.

5. Does the PurgeAlarm™ Visual Alarm Indicator have a sounder?

A 85dB Sounder (2900Hz) is available as an option to provide an audible alarm or instead of the additional red light.



© HFT®